

Glass Scratch Repair Kit Including 110V Bosch Grinder (Model: F.GRK.001)





n performing a scratch repair on tempered first use the Speed Adjustable Angle der and the No. 1 Grinding Pad to perform ugh grind. Note that the grinding pad must vel with the glass and the speed adjusted to thy 2500 - 3000 rpm.



n using the No. 1 Grinding Pad, you can orm the task without the need for water. ough, if using non-tempered glass, the perature of the glass should be controlled does not overheat, which in turn could ter the class.



Drice you have created a rough grind on the glas epilae the No. 1 Grinding Pad with the No. 2 Srinding Pad for a finer grind. 'Ilease note that the grinding area for the No. 2 Srinding Pad should be greater than the area for he No. 1 Grinding Pad to avoid any deformation.



In order to ensure the highest effectiveness grinding, the glass powder on the Grinding Pad should be cleaned away periodically during the process.



After completion of the fine grinding, replace the No. 2 Grinding Pad with a polishing pad and proceed with polishing the glass.



During the polishing process, add water continuously and observe the polishing effect throughout.



Once finished polishing, the scratch should now be repaired. A revolutionary glass repair kit that quickly removes even the toughest of scratches from glass.

Attributes: Product Code: F.GRK.001 Unit Of Sale: Kit















