




Glass Scratch Repair Kit Including 220V Bosch Grinder (Model: F.GRK.001.220)



Attributes:

Product Code: F.GRK.001.220

Unit Of Sale: Kit



When performing a scratch repair on tempered glass, first use the Speed Adjustable Angle Grinder and the No. 1 Grinding Pad to perform a rough grind. Note that the grinding pad must be level with the glass and the speed adjusted to roughly 2500 - 3000 rpm.



When using the No. 1 Grinding Pad, you can perform the task without the need for water. Although, if using non-tempered glass, the temperature of the glass should be controlled so it does not overheat, which in turn could shatter the glass.



Once you have created a rough grind on the glass, replace the No. 1 Grinding Pad with the No. 2 Grinding Pad for a finer grind. Please note that the grinding area for the No. 2 Grinding Pad should be greater than the area for the No. 1 Grinding Pad to avoid any deformation.



In order to ensure the highest effectiveness of grinding, the glass powder on the Grinding Pad should be cleaned away periodically during the process.

